

Test Code	TAT	Test Code Name	Test Code Description	Samples Accepted:	Samples Accepted at:
ZA0059		Dust Collector			
Z045CC		Air-O-Cell Cassette Individual			
Z045CC		25mm Micro-Vac Carpet/Dust Sampling Cassettes			
Z008BA		Asbestos PCM Cassette, Individual			
Z008BA		Asbestos PCM Cassette box of 50			
CSI010		Air-O-Cell CSI box of 10			
CSI002		Air-O-Cell CSI pack of 2			
BT0050		Bio-Tape box of 50			
AOC050		Air-O-Cell Cassette box of 50			
AOC-WS10		Air-O-Cell Inner Wall Sampling Tubes (pack of 10)			
AERO019		High Volume Rotary Vane Pump Daily Rental			
AERO011		Allergenco D Individual			
AER-ALAI-500		Aerotrapp (Charger Ratometer, Sampler)			
3005	3 Day	Air, Total Dust Analysis, NiOSH 0500, TAT 3 Days	Total dust analysis by gravimetric of air samples.	Monday - Friday	California
3004	5-7 Days	Air, PCM, NIOSH 7400, TAT 5-7 Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	24 Hour	Air, PCM, NIOSH 7400, TAT 24 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	Same Day	Air, PCM, NIOSH 7400, TAT Same Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	2 Hour	Air, PCM, NIOSH 7400, TAT 2 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado; Virginia
3004	4 Hour	Air, PCM, NIOSH 7400, Colorado Only, TAT 4 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado
3004	5-7 Days	Air, PCM, NIOSH 7400, Colorado Only, TAT 5 Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado
3004	5-7 Days	Air, PCM, NIOSH 7400, TAT 5-7 Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	24 Hour	Air, PCM, NIOSH 7400, TAT 24 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	Same Day	Air, PCM, NIOSH 7400, TAT Same Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Virginia
3004	2 Hour	Air, PCM, NIOSH 7400, TAT 2 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado; Virginia
3004	4 Hour	Air, PCM, NIOSH 7400, Colorado Only, TAT 4 hour	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado
3004	5-7 Days	Air, PCM, NIOSH 7400, Colorado Only, TAT 5 Day	NIOSH Method 7400, quantification of airborne fibers	Monday - Friday	Colorado
3003	5-7 Days	Bulk, PLM Particle Characterization, TAT 5-7 Day	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3003	2-3 Day	Bulk, PLM Particle Characterization, TAT 2 Day	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3002	3 Hour	Bulk, PLM, TAT 3 Hour	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	Same Day	Bulk, PLM, TAT Same Day	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	24 Hour	Bulk, PLM, Colorado Only TAT 24 hour	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3002	2 Hour	Bulk, PLM, TAT 2 hour	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	24 Hour	Bulk, PLM Particle Characterization, TAT 24 hour	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3002	5-7 Days	Bulk, PLM, TAT 5-7 Day	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	5-7 Days	Bulk, PLM, Colorado Only, TAT 5 Day	EPA Method 600/R93/116	Monday - Friday	Colorado
3002	24 Hour	Bulk, PLM, Colorado Only TAT 4 hour	EPA Method 600/R93/116	Monday - Friday	Colorado
3002	24 Hour	Bulk, PLM, TAT 24 hour	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3002	Same Day	Bulk, PLM, TAT Same Day	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	24 Hour	Bulk, PLM, Colorado Only TAT 24 hour	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3002	2 Hour	Bulk, PLM, TAT 2 hour	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	5-7 Days	Bulk, PLM, TAT 5-7 Day	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	3 Hour	Bulk, PLM, TAT 3 Hour	EPA Method 600/R93/116,	Monday - Friday	Arizona; California; Colorado; Virginia
3002	5-7 Days	Bulk, PLM, Colorado Only, TAT 5 Day	EPA Method 600/R93/116	Monday - Friday	Colorado
3002	24 Hour	Bulk, PLM, Colorado Only TAT 4 hour	EPA Method 600/R93/116	Monday - Friday	Colorado
3002	24 Hour	Bulk, PLM, TAT 24 hour	EPA Method 600/R93/116	Monday - Friday	Arizona; California; Colorado; Virginia
3001A	24 Hour	Bulk, PLM, Point Count 1000, TAT 24 hour	EPA Method 600/R-93/116;	Monday - Friday	Colorado
3001A	2-3 Day	Bulk, PLM, Point Count 1000, TAT 2 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001A	5-7 Days	Bulk, PLM, Point Count 1000, TAT 5-7 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001A	24 Hour	Bulk, PLM, Point Count 1000, TAT 24 hour	EPA Method 600/R-93/116;	Monday - Friday	Colorado
3001A	5-7 Days	Bulk, PLM, Point Count 1000, TAT 5-7 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001A	2-3 Day	Bulk, PLM, Point Count 1000, TAT 2 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	24 Hour	Bulk, PLM, Point Count 400, TAT 24 hour	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	48 Hour	Bulk, PLM, Point Count 400, TAT 2 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia

3001	5-7 Days	Bulk, PLM, Point Count 400, TAT 5-7 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	6 Hour	Bulk, PLM, Point Count 400, TAT 6 hour	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	5-7 Days	Bulk, PLM, Point Count 400, TAT 5-7 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	48 Hour	Bulk, PLM, Point Count 400, TAT 2 Day	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	24 Hour	Bulk, PLM, Point Count 400, TAT 24 hour	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
3001	6 Hour	Bulk, PLM, Point Count 400, TAT 6 hour	EPA Method 600/R-93/116	Monday - Friday	Arizona; California; Virginia
120518		Allergenco-D Inner Wall Samplers, 10-pack		Monday - Friday	
120515		Allergenco D box of 50		Monday - Friday	
		Air-O-Cell Cassette box of 10		Monday - Friday	
		Air-O-Cel In-Line Calibration Adaptor		Monday - Friday	
		Micro-Vac Carpet Sampling Kit		Monday - Friday	