

Test Code	Turnaround Time	Test Name	Samples Accepted:	Supplies
1064	3-5 Days	Bacterial Speciation ID Add On, TAT 3-5 Days	Monday - Friday	TSA Air Sampling Plates, 15x100mm; TSA Contact plates,
1091	6 Weeks	Surface/Wipe, Mycobacterium (NTM) Culture & Count, TAT 6 Weeks	Monday - Friday	Middlebrook
1104	2-3 Day	Surface, USP 797 Bacterial Counts with Genus ID, TAT 2-3 Day	Monday - Friday	SAS Sampler; TSA Contact plates, 15x60mm
1106	5-7 Days	Surface/Wipe, USP 797 Fungal Counts with Genus ID, TAT 6 Days	Monday - Friday	MEA Contact plates, 15x60mm
1107	2-3 Day	Air, USP 797 Bacterial Counts with Genus ID, TAT 2-3 Day	Monday - Friday	SAS Sampler; TSA Air Sampling Plates, 15x100mm
1108	5-7 Days	Air, USP 797 Fungal Counts with Genus ID, TAT 5-7 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm; MEA Contact plates, 15x60mm; SAS Sampler
1109	3 Days	Surface/Wipe, Culture, USP 797 Glove Fingertip Bacterial Counts Only, TAT 3 Days	Monday - Friday	TSA Contact plates, 15x60mm
1109.1	2-3 Day	Surface/Wipe, Culture, USP 797 Glove Fingertip Bacterial Counts with Genus ID, TAT 3 Days	Monday - Friday	TSA Contact plates, 15x60mm
1110	5-7 Days	Surface/Wipe, Culture, USP 797 Glove Fingertip Fungal Counts Only, TAT 5-7 Day	Monday - Friday	TSA Contact plates, 15x60mm
1110.1	5-7 Days	Surface/Wipe, Culture, USP 797 Glove Fingertip Fungal Counts with Genus ID, TAT 5-7 Day	Monday - Friday	TSA Contact plates, 15x60mm
1113	5-7 Days	Air, USP 797 Bacterial Speciation up to 3 Isolates, TAT 5-7 Day	Monday - Friday	TSA Air Sampling Plates, 15x100mm
1114	5-7 Days	Air, USP 797 Fungal Speciation up to 3 Isolates, TAT 5-7 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm; SabDex Air Sampling
1115	5-7 Days	Surface/Wipe, USP 797 Bacterial Speciation up to 3 Isolates, TAT 5-7 Days	Monday - Friday	TSA Contact plates, 15x60mm
1116	5-7 Days	Surface, USP 797 Fungal Speciation up to 3 Isolates, TAT 5-7 Day	Monday - Friday	MEA Contact plates, 15x60mm; SabDex Contact plates, 15x60mm
1117	2-3 Weeks	Surface/Wipe, Culture Full Fungal Speciation, TAT 2-3 Weeks	Monday - Friday	TSA Contact plates, 15x60mm
1118	2-3 Weeks	Surface/Wipe, Culture, Bacterial Full Speciation, TAT 2-3 Weeks	Monday - Friday	MEA Contact plates, 15x60mm
1127	2-3 Weeks	Air, Culture Full Fungal Speciation, TAT 2-3 Weeks	Monday - Friday	MEA Air Sampling Plates 15x100mm; SabDex Air Sampling
1128	2-3 Weeks	Air, Air Culture Full Bacterial Speciation	Monday - Friday	MEA Air Sampling Plates 15x100mm
1135	3-5 Days	Surface/Wipe, Listeria, Culture Screen Analysis, TAT 3-5 Day	Monday - Friday	Swab
1152	3 Days	Air, Positive Bacterial Control Sample, TAT 3 Day	Monday - Friday	TSA Air Sampling Plates, 15x100mm
1153	6 Day	Air, Positive Fungal Control Sample, TAT 6 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm; SabDex Air Sampling
1202	3 Day	Surface, Bacteria, Counts ONLY, Single Plate Protocol, TAT 5 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1202.1	5 Days	Surface, Fungal, Counts ONLY, Single Plate Protocol, TAT 5 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1202.2	2-3 Day	Surface, Culture, Bacterial Counts with ID, Single Plate Protocol, TAT 2-3 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1202.3	5 Days	Surface, Fungal, Counts with ID, Single Plate Protocol, TAT 5 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1202.5	2-3 Day	Air, Culture, Bacterial Counts with ID, Single Plate Protocol, TAT 2-3 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1202.6	5 Days	Air, Culture, Fungal Counts with ID, Single Plate Protocol, TAT 5 Day	Monday - Friday	TSA Air Sampling Plates, 15x100mm
1202.7	2-3 Day	Air, Culture, Bacterial Counts ONLY, Single Plate Protocol, TAT 2-3 Days	Monday - Friday	TSA Air Sampling Plates, 15x100mm
1202.8	5-7 Days	Air, Culture, Fungal Counts ONLY, Single Plate Protocol, TAT 5 Days	Monday - Friday	MEA Air Sampling Plates 15x100mm
1204	3 Days	Surface/Wipe, USP 797 Culture Bacterial Counts Only, TAT 3 Days	Monday - Friday	TSA Contact plates, 15x60mm
1206	5-7 Days	Surface/Wipe, USP 797 Culture Fungal Counts Only, TAT 5-7 Days	Monday - Friday	MEA Contact plates, 15x60mm
1207	3 Days	Air, USP 797 Culture Bacterial Counts Only, TAT 3 Day	Monday - Friday	TSA Air Sampling Plates, 15x100mm
1208	5-7 Days	Air, USP 797 Culture Fungal Counts Only, TAT 5-7 Day	Monday - Friday	MEA Air Sampling Plates 15x100mm
1209	7-12 Days	MEDIUM-RISK (Basic) Media Fill Analysis ONLY	Monday - Friday	
1211	7-12 Days	LOW-RISK Media Fill Analysis ONLY	Monday - Friday	
1212	7-12 Days	MEDIUM-RISK (Comprehensive) Media Fill Analysis ONLY	Monday - Friday	
1213	7-12 Days	HIGH-RISK Media Fill Analysis ONLY	Monday - Friday	
2064.5	5 Days	MALDI-TOF Species Identification per isolate, TAT 5 Days	Monday - Friday	
3080	48 Hour	Water, USP, Sterility Testing, TAT 48 Hour	Monday - Friday	120 ml bottle w/Sodium Thiosulfate
3080.1	14 Day	Water, USP, Sterility Check for Bacti/Fungi, Small Volume, TAT 14 Day	Monday - Friday	120 ml bottle w/Sodium Thiosulfate
3080.2	3-5 Days	Water, USP, Positive Sterility Subculture Fee, TAT 3-5 Day	Monday - Friday	120 ml bottle w/Sodium Thiosulfate
3080.4	5-10 Days	Water, USP, Positive Identification Bag, Bacterial and Fungal, TAT 5-10 Day	Monday - Thursday	120 ml bottle w/Sodium Thiosulfate
3080.5	14 Day	Water, USP, Bacteria Sterility Check, Large Volume, TAT 14 Day	Monday - Friday	120 ml bottle w/Sodium Thiosulfate
3104	2-3 Day	Surface, USP 1116, Culture, Bacterial Counts with ID: SOP 2.23, TAT 2-3 Days	Monday - Friday	TSA Contact plates, 15x60mm
3106	5-7 Days	Surface, USP 1116 Culture, Surface, Fungal Counts with ID: SOP 3.9, TAT 5-7 Days	Monday - Friday	TSA Contact plates, 15x60mm
3107	2-3 Day	Surface, USP 1116 Culture, Air, Bacterial Counts with ID: SOP 2.2, TAT 2-3 Days	Monday - Friday	TSA Contact plates, 15x60mm
3108	5-7 Days	Surface, USP 1116 Culture, Air, Fungal Counts with ID: SOP 3.2, TAT 2-3 Days	Monday - Friday	TSA Contact plates, 15x60mm