

Aerobiology Laboratory - VA  
43760 Trade Center Place  
Sterling, Virginia 20166  
Attn: Chris Blevins  
Project: **Sample Report**  
Condition of Sample(s) Upon Receipt: Acceptable

Date Collected: 02/10/2021  
Date Received: 02/10/2021  
Date Analyzed: 02/17/2021  
Date Reported: 02/17/2021  
Project ID: 21014090  
Page 1 of 3

Client Sample #: 1  
Sample Location: Attic Truss  
Test: 1097, Surface/Wipe, Cryptococcus and Fungal Count w/ Genus ID  
Results: **10 CFU/in<sup>2</sup>**

Lab Sample #: 21014090-001

Area: **2 (in<sup>2</sup>)**

Organism(s) Isolated:	Raw Count	CFU/in <sup>2</sup>	% Total	MRL
Cladosporium species	2	10	100	5
	2	10	~100%	

Comments: No Cryptococcus neoformans isolated.

Client Sample #: 2  
Sample Location: Attic  
Test: 1098, Air, Cryptococcus and Fungal Count w/ Genus ID  
Positive Hole Corrected Result: **41 CFU/m<sup>3</sup>**

Lab Sample #: 21014090-002

Positive Hole: **219**  
Air Volume: **100 (L)**

Organism(s) Isolated:	Raw Count	CFU/m <sup>3</sup>	% Total	MRL
Cladosporium species	2	20	50	10
Non-sporulating colonies	2	20	50	10
	4	40	~100%	

Comments: No Cryptococcus neoformans isolated.

Client Sample #: 3  
Sample Location: Attic Truss  
Test: 1099, Bulk, Cryptococcus and Fungal Count w/ Genus ID  
Results: **1600 CFU/g**

Lab Sample #: 21014090-003

Mass Analyzed: **0.5 (g)**

Organism(s) Isolated:	Raw Count	CFU/g	% Total	MRL
Epicoccum species	1	200	13	200
Non-sporulating colonies	4	800	50	200
Paecilomyces species	3	600	38	200
	8	1600	~100%	

Comments: No Cryptococcus neoformans isolated.

Aerobiology Laboratory - VA  
 43760 Trade Center Place  
 Sterling, Virginia 20166  
 Attn: Chris Blevins  
 Project: **Sample Report**  
 Condition of Sample(s) Upon Receipt: Acceptable

Date Collected: 02/10/2021  
 Date Received: 02/10/2021  
 Date Analyzed: 02/17/2021  
 Date Reported: 02/17/2021  
 Project ID: 21014090  
 Page 2 of 3

Client Sample #: 4  
 Sample Location: Sink  
 Test: 1095, Water, Cryptococcus and Fungal Count w/ Genus ID  
 Results: **30 CFU/mL**

Lab Sample #: 21014090-004

Liquid Volume: **1 (mL)**

Organism(s) Isolated:	Raw Count	CFU/mL	% Total	MRL
Acremonium species	3	30	100	10
	3	30	~100%	

Comments: No Cryptococcus neoformans isolated.

Aerobiology Laboratory - VA  
43760 Trade Center Place  
Sterling, Virginia 20166  
Attn: Chris Blevins  
Project: **Sample Report**  
Condition of Sample(s) Upon Receipt: Acceptable

Date Collected: 02/10/2021  
Date Received: 02/10/2021  
Date Analyzed: 02/17/2021  
Date Reported: 02/17/2021  
Project ID: 21014090  
Page 3 of 3

**Footnotes and Additional Report Information**

**Debris Rating Table**


1	Minimal (<5%) particulate present	Reported values are minimally affected by particulate load.
2	5% to 25% of the trace occluded with particulate	Negative bias is expected. The degree of bias increases directly with the percent of the trace that is occluded.
3	26% to 75% of the trace occluded with particulate	Negative bias is expected. The degree of bias increases directly with the percent of the trace that is occluded.
4	75% to 90% of the trace occluded with particulate	Negative bias is expected. The degree of bias increases directly with the percent of the trace that is occluded.
5	Greater than 90% of the trace occluded with particulate	Quantification not possible due to large negative bias. A new sample should be collected at a shorter time interval or other measures taken to reduce particulate load.

Aerobiology Laboratory Associates, Inc. shall be responsible for all the information provided in the report, except when information is provided by the customer. Data provided by a customer can affect the validity of results and shall be clearly identified. Results apply to the samples as received. Aerobiology Laboratory Associates, Inc. is not responsible for the sampling activity, such as air and water volume, area, and mass unit. The report shall not be reproduced except in full without the approval of the laboratory to ensure that parts of a report are not taken out of context. Data interpretation of this report will be the client responsibility based on their sampling.

1. Penicillium/Aspergillus group spores are characterized by their small size, round to ovoid shape, being unicellular, and usually colorless to lightly pigmented. There are numerous genera of fungi whose spore morphology is similar to that of the Penicillium/Aspergillus type. Two common examples would be Paecilomyces and Acremonium. Although the majority of spores placed in this group are Penicillium, Aspergillus, or a combination of both. Keep in mind that these are not the only two possibilities.
2. Ascospores are sexually produced fungal spores formed within an ascus. An ascus is a sac-like structure designed to discharge the ascospores into the environment, e.g. Ascobolus.
3. Basidiospores are typically blown indoors from outdoors and rarely have an indoor source. However, in certain situations a high basidiospore count indoors may be indicative of a wood decay problem or wet soil.
4. The colorless group contains colorless spores which were unidentifiable to a specific genus. Examples of this group include Acremonium, Aphanocladium, Beauveria, Chrysosporium, Engyodontium microconidia, yeast, some arthrospores, as well as many others.
5. Hyphae are the vegetative mode of fungi. Hyphal elements are fragments of individual Hyphae. They can break apart and become airborne much like spores and are potentially allergenic. A mass of hyphal elements is termed the mycelium. Hyphae in high concentration may be indicative of colonization.
6. Dash (-) in this report, under raw count column means 'not detected (ND)'; otherwise 'not applicable' (NA).
7. The positive-hole correction factor is a statistical tool which calculates a probable count from the raw count, taking into consideration that multiple particles can impact on the same hole; for this reason the sum of the calculated counts may be less than the positive hole corrected total.
8. Due to rounding totals may not equal 100%.
9. Analytical Sensitivity for each spores is different for Non-viable sample when the spores are read at different percentage. Analytical Sensitivity is calculated as  $\text{spr/m}^3$  divided by raw count.  $\text{spr/m}^3 = \text{raw counts} \times (100/\% \text{ read}) \times (1000/\text{Sample volume})$ . If Analytical Sensitivity is 13  $\text{spr/m}^3$  at 100% read, Analytical Sensitivity at 50% read would be 27  $\text{spr/m}^3$ , which is 2 times higher. Analytical Sensitivity provided on the report is based on an assumed 100% of the trace being analyzed.
10. Minimum Reporting Limits (MRL) for BULKs, DUSTS, SWABS, and WATER samples are a calculation based on the sample size and the dilution plate on which the organism was counted. Results are a compilation of counts taken from multiple dilutions and multiple medias. This means that every genus of fungi or bacteria recovered can be counted on the plate on which it is best represented.
11. If the final quantitative result is corrected for contamination based on the blank, the blank correction is stated in the sample comments section of the report.
12. The results in this report are related to this project and these samples only.
13. For samples with an air volume of < 100L, the number of significant figures in the result should be considered (2) two. For samples with air volumes between 100-999L, the number of significant figures in the result should be considered (3) three. For example, a sample with a result of 55,443  $\text{spr/m}^3$  from a 75L sample using significant figures should be considered 55,000. The same result of 55,443 from a 150L sample using significant figures should be considered 55,400  $\text{spr/m}^3$ .
14. If the In/Out ratio is greater than 100 times it is indicated >100/1, rather than showing the real value.

**Terminology Used in Direct Exam Reporting**

**Conidiophores are a type of modified hyphae from which spores are born. When seen on a surface sample in moderate to numerous concentrations they may be indicative of fungal growth.**



Suzanne S. Blevins, B.S., SM (ASCP)  
Laboratory Director